

U.S. PATENT #D623,913 - OTHER U.S. AND INTERNATIONAL PATENTS PENDING







Lock Hardwood Wrench<sup>\*\*</sup> tool onto the joist. Tip of the locking dog should be approximately 1" away from deck board. This will allow cam to move fluidly and lock with ease. If cam does not lock easily or requires much force, the Hardwood Wrench is most likely too close to the board you are installing.



Swing handle until board is straightened. Again, the handle should swing easily with little effort. If not, check positioning of the tool as described in step #1.



Locks in place for hands free holding. Once locked, fasten deck board and move to the next joist.

## WWW.HARDWOODWRENCH.COM

MANUFACTURED BY THE IPE CLIP® FASTENER COMPANY LLC. TOLL FREE 866.427.2547 LOCAL 941.896.9851